



User's Manual

Opiates Oral Fluid ELISA Kit



DEIA-NS2308-13



96T



This product is for research use only and is not intended for diagnostic use.

For illustrative purposes only. To perform the assay the instructions for use provided with the kit have to be used.

Creative Diagnostics

 Address: 45-1 Ramsey Road, Shirley, NY 11967, USA

 Tel: 1-631-624-4882 (USA) 44-161-818-6441 (Europe)  Fax: 1-631-938-8221

 Email: info@creative-diagnostics.com  Web: www.creative-diagnostics.com

PRODUCT INFORMATION

Intended Use

For the determination of trace quantities of Morphine and/or other opiates and metabolites in human oral fluid.

General Description

Opiates Oral Fluid ELISA (Enzyme-Linked ImmunoSorbent Assay) test kit is a qualitative one-step kit designed for use as a screening device for the detection of drugs and/or their metabolites. It is recommended that all suspect samples be confirmed by a quantitative method such as gas chromatography/mass spectrometry (GC/MS).

Principles of Testing

Test kit operates on the basis of competition between the drug or its metabolite in the sample and the drug-enzyme conjugate for a limited number of antibody binding sites. First, the sample or control is added to the microplate. Next, the drug-enzyme conjugate is added and the mixture is incubated for 45 minutes at room temperature. During this incubation, the drug in the sample or the drug-enzyme conjugate binds to antibody immobilized in the microplate wells. After incubation, the plate is washed to remove any unbound sample or drug-enzyme conjugate. The presence of bound drug-enzyme conjugate is recognized by the addition of K-Blue Substrate (TMB). After a 30 minute substrate incubation, the reaction is halted with the addition of an acid stop. The test can be read visually or with a microplate reader equipped with a 450 nm filter. The extent of color development is inversely proportional to the amount of drug in the sample or control. In other words, the absence of the drug in the sample will result in a dark yellow color, whereas the presence of the drug will result in light yellow to no color development.

Reagents And Materials Provided

1. Wash Buffer Concentrate (10x): 20 mL. Phosphate buffered saline solution with a surfactant. Dilute 10 fold with deionized or ultrapure water before use. Diluted wash buffer is used to wash all unbound conjugate and samples from the plate after the conjugate incubation.
2. K-Blue Substrate: 20 mL (ready-to-use). Stabilized 3, 3', 5, 5' Tetramethylbenzidine (TMB) plus Hydrogen Peroxide (H₂O₂) in a single bottle. It is used to develop the color in the wells after washing. Light Sensitive.
3. Drug-Enzyme Conjugate: 14 mL (ready-to-use). Drug-horseradish peroxidase conjugate. Do not dilute.
4. Antibody Coated Plate: A 96 well Costar plate, in strips of 8 break away wells, coated with anti-drug antiserum. The plate is ready for use as is. Do not wash.
5. Acid Stop Solution: 14 mL (ready-to-use). 1 N H₂SO₄ used to stop the enzyme reaction.

Materials Required But Not Supplied

1. Deionized water.
2. Precision pipettes that range from 10 µL - 1000 µL and disposable tips.

3. Graduated cylinder to dilute and mix wash buffer.
4. Plate cover or plastic film to cover plate during incubation.
5. Microplate reader with a 450 nm filter.

OPTIONAL TEST MATERIALS

1. Oral Fluid Multi-Analyte Calibrators (contact CD Creative-diagnostics)

Storage

This kit can be used until the expiration date on the label when stored refrigerated at 2-8°C.

Specimen Collection And Preparation

This assay was designed to be compatible with the Oral Fluid Collection Device, which has a built-in 1:4 sample dilution. No further dilution is recommended for optimal assay performance.

Assay Procedure

Notes:

1. Desiccant bag must remain in foil pouch with unused strips. Keep ziplock pouch sealed when not in use to maintain a dry environment.
2. Use clean pipette tips for the buffer, drug-enzyme conjugate, controls and samples.
3. Before pipetting a reagent, rinse the pipette tip three times with that reagent.
4. When pipetting into the wells, DO NOT allow the pipette tip to touch the inside of the well or any of the reagent already inside the well. This may result in cross contamination.
5. Controls and samples should be assayed in duplicate.
6. Before substrate addition, wipe the outside bottom of the wells with a lint-free wiper to remove dust and fingerprints.
7. Gently mix specimens and reagents before use. Avoid vigorous agitation.

Procedure:

1. Determine the number of wells to be used.
2. Gently mix the ready-to-use drug-enzyme conjugate solution by inversion. Do not vortex. Store unused conjugate at 2-8°C.
3. Add 20 µL of sample or controls to the appropriate wells in duplicate.
4. Add 100 µL of the drug-enzyme conjugate to each well. For manual runs use 8-channel pipette or 12-channel pipette for rapid addition.
5. For manual runs, mix by gently shaking plate. A microplate shaker may be used.
6. Cover plate with plastic film or plate cover and incubate at room temperature for 45 minutes.
7. During the conjugate incubation, dilute concentrated wash buffer 10 fold with deionized water (i.e. 20 mL of concentrated wash buffer plus 180 mL of deionized water). Mix thoroughly. Diluted wash buffer is stable for 5 days at room temperature or 7 days at 2-8°C.

8. Once the incubation is complete, dump or aspirate the liquid from the wells. Tap the plate on a clean lint-free towel to remove any remaining liquid in the wells.
9. Wash each well with 300 μL of diluted wash buffer. Manual Wash: For manual wash procedures repeat for a total of 3 washings, invert and tap dry the plate following each step. After completing the last wash step wipe the bottom of the wells with a lint-free towel to remove any liquid on the outside of the wells. Automated Wash: If an automated plate washer is used wash the plate for a total of 5 washings with 300 μL of diluted wash buffer. It is important for the automated washer to conduct a final aspirate cycle to eliminate residual amounts of wash buffer. Residual amounts of buffer in the wells will affect assay performance. **Note: DI water should never be used for the plate wash.**
10. Add 100 μL of K-Blue Substrate to each well. For manual runs, use a multi-channel pipette for best results.
11. Cover plate with plastic film or plate cover and incubate at room temperature for 30 minutes.
12. Add 100 μL of Acid Stop (1N H_2SO_4) to each well to stop enzyme reaction. Mix gently before measuring absorbance. For automated systems a 10 second shake is sufficient. Measure the absorbance at a wavelength of 450 nm. Wells should be read within 2 hours of stopping the reaction.


Interpretation Of Results

Positive Result: Samples with an absorbance less than or equal to the laboratory's designated cutoff calibrator should be presumed positive. All positive samples should be confirmed by a quantitative method such as GC/MS.

Negative Result: Samples with an absorbance greater than the laboratory's designated cutoff calibrator should be presumed negative.

Note: The kit was designed for screening purposes only. It is recommended that all suspect samples be confirmed by a quantitative method such as GC/MS or HPLC.

Typical Standard Curve



Sensitivity

Compound: Morphine

I-50 in Oral Fluid Buffer: 4.2 ng/mL

I-50 in Oral Fluid (1:4 dilution: 1 part sample to 3 parts Oral Fluid Buffer): 21.2 ng/mL

The term I-50 is used to define the sensitivity of the test. This number is derived from a standard curve generated with the drug. The drug concentration that shows 50% less color activity than the zero standard is considered to be the I-50.

Specificity

Compound	Compound Concentration (ng/mL)	Morphine Equivalents (ng/mL)	% Cross-Reactivity
Morphine	4.2	4.2	100
Ethylmorphine	2.6	4.2	162
Codeine	3.1	4.2	136
6-Acetylcodeine	4.1	4.2	103
6-Acetylmorphine	4.9	4.2	86
Heroin/Diacetylmorphine	4.9	4.2	86
Dihydrocodeine	11	4.2	39
Morphine-6-β-D-Glucuronide	12	4.2	35
Dihydromorphine	15	4.2	28
Morphine-3-β-D-Glucuronide	17	4.2	25
Thebaine	19	4.2	23
Hydrocodone	25	4.2	17
Hydromorphone	35	4.2	12
Levorphanol	86	4.2	5
Nalorphine	110	4.2	4
Oxymorphone	2,100	4.2	0.2
Oxycodone	2,800	4.2	0.2
Norcodeine	3,100	4.2	0.2
Meperidine	3,500	4.2	0.1
Diprenorphine	4,500	4.2	0.1
Normorphine	4,500	4.2	0.1
Norbuprenorphine	>1,000	4.2	<0.4
Buprenorphine	>1,000	4.2	<0.4
Noroxymorphone	>1,000	4.2	<0.4

Note: Morphine equivalents represents 50% B/B₀ assay displacement in Oral Fluid Buffer.

Precautions

1. DO NOT use kits or components beyond expiration date.
2. DO NOT mix conjugates and plates from different kit lots.
3. DO NOT pipette reagents by mouth.
4. Pour K-Blue Substrate out of the bottle into a clean reservoir. To prevent contamination of the substrate, DO NOT pipette out of the bottle.
5. All specimens should be considered potentially infectious. Exercise proper handling precautions.

6. Keep plate covered except when adding reagents, washing or reading.
7. Kit components should be refrigerated when not in use.
8. Use aseptic technique when opening and removing reagents from vials and bottles.
9. DO NOT smoke, eat or drink in areas where specimens or reagents are being handled.
10. DO NOT substitute DI water for the wash step of this protocol. Use only our wash buffer.
11. DO NOT reuse wells, they are for one use only.

